

First cut the black and the grey Wires.  
Now solder the wires like shown below.

